



WIRE ADJUSTMENT INSTRUCTIONS


UNPACK THE LIGHT FIXTURE




1

 REMOVE THE TOP PLATE (a) FROM
 PENDANT BODY (b) USING THE
 PROVIDED TOOL (c)



2

 CAREFULLY PULL OUT TOP PLATE (a)
 TO ACCESS THE WIRE RESTRAINT (d)



3

 LOOSEN WIRE RESTRAINT (d) SO
 THAT THE TOP PLATE (a) CAN MOVE
 FREELY ALONG THE CORD


4

 POSITION TOP PLATE (a) AT DESIRED
 PENDANT HEIGHT AND RE-INSTALL
 THE WIRE RESTRAINT (d)



5

 CAREFULLY PUSH EXCESS CORD
 INTO THE PENDANT BODY (b) AND
 ATTACH THE TOP PLATE


6

MAGNETIC LIGHT FIXTURES
INSTALLATION INSTRUCTIONS

INSTALLING THE LIGHT FIXTURE



CORRECT STEPS FOR MOVING THE LIGHT FIXTURES

