



WIRE ADJUSTMENT INSTRUCTIONS

REMOVE THE TOP PLATE (a) FROM
PENDANT BODY (b) BY TURNING
COUNTER CLOCKWISE




1

LOOSEN THE WIRE RESTRAINT (c)
SO THAT THE TOP PLATE (a) CAN MOVE
FREELY ON THE CORD




2

POSITION TOP PLATE (a) AT DESIRED
PENDANT HEIGHT AND RE-INSTALL
THE WIRE RESTRAINT (c)



3


CAREFULLY PUSH EXCESS CORD
INTO THE PENDANT BODY (b) AND
ATTACH THE TOP PLATE (a)



4

MAGNETIC LIGHT FIXTURES
INSTALLATION INSTRUCTIONS

INSTALLING THE LIGHT FIXTURE



CORRECT STEPS FOR MOVING THE LIGHT FIXTURES

